

# ELECTROCARDIOGRAM (ECG EKG)

Authored by  
**mohammad looti**

October 10, 2025

## RECOMMENDED CITATION

mohammad looti (2025). *ELECTROCARDIOGRAM (ECG EKG)*. PSYCHOLOGICAL SCALES. Retrieved from <https://scales.arabpsychology.com/?p=42652>

## ELECTROCARDIOGRAM (ECG EKG)

**Primary Disciplinary Field(s):** Cardiology, Clinical Physiology, Diagnostic Medicine

### 1. Core Definition

The **Electrocardiogram** (ECG), commonly abbreviated as EKG (derived from the original German term *Elektrokardiogramm*), is a foundational diagnostic tool in medicine, specifically within the realm of cardiology. It functions as a non-invasive graphical representation of the electrical activity generated by the depolarization and repolarization of the cardiac muscle cells. This electrical impulse controls the heart's contraction cycle. The resulting tracing is a wave-like pattern recorded over time, typically printed on calibrated paper or displayed digitally on a monitor. The purpose of the ECG is to capture the strength and timing of these impulses as they travel through the heart's conduction system, thereby assessing the functional status of the heart.

By analyzing the morphology, amplitude, and timing of these characteristic waves, clinicians can infer the functional health of the heart and identify a wide range of cardiac pathologies. Essentially, the ECG provides a temporal map of the heart's electrical cycle, crucial for diagnosing issues ranging from life-threatening arrhythmias to myocardial ischemia. It enables the measurement of the heart rate, rhythm, and the electrical axis, providing direct evidence of whether the heart is beating normally (sinus rhythm) or experiencing irregularities. Furthermore, specific changes in the waveform morphology can indicate structural damage, electrolyte imbalances, or the effects of medications. Because it is quick, inexpensive, and portable, the ECG remains one of the most frequently used tests in emergency departments, critical care units, and outpatient clinics globally.

### 2. Etymology and Historical Development

The history of the electrocardiogram spans the late 19th and early 20th centuries, building upon early investigations into bioelectricity. The foundational work is often attributed to the British physiologist **Augustus Waller**, who, in 1887, first demonstrated that electrical activity from the human heart could be reliably recorded from the surface of the body using a capillary electrometer. Although Waller succeeded in recording the heart's electrical fluctuations, his instruments were cumbersome and lacked the precision necessary for clinical utility, making the recordings difficult to interpret accurately.

The true revolution in electrocardiography came with the Dutch physiologist **Willem Einthoven**. Working in Leiden, Einthoven dramatically improved the technology by inventing the highly sensitive **string galvanometer** in 1901. This device utilized a thin quartz fiber coated with silver, suspended in a strong magnetic field, allowing it to register the minuscule electrical currents produced by the heart with unprecedented accuracy. Einthoven standardized the measurement

technique, defining the P, Q, R, S, and T waves, which remain the essential nomenclature of modern ECG analysis. He established the concept of the **Einthoven Triangle**, which standardized the placement of the three bipolar limb leads (Leads I, II, and III). For his monumental contribution to medical diagnostics, Einthoven was awarded the Nobel Prize in Physiology or Medicine in 1924. His foundational work laid the basis for modern clinical cardiology and diagnostic electrophysiology, and the persistent use of EKG is a nod to the original German/Dutch spelling (*Elektrokardiogramm*).

### 3. Physiological Basis of the ECG

The electrical activity detected by the ECG originates in the heart's intrinsic conduction system. The process begins in the **sinoatrial (SA) node**, often termed the heart's natural pacemaker, located in the right atrium. The SA node spontaneously generates an impulse that spreads rapidly across the atria, resulting in atrial depolarization (contraction). This impulse then reaches the **atrioventricular (AV) node**, which introduces a crucial physiological delay. This delay is essential as it allows the ventricles to fill completely with blood before the next contraction phase begins.

After the AV node delay, the impulse travels rapidly down the Bundle of His, through the right and left bundle branches, and finally via the network of **Purkinje fibers**, which distribute the impulse quickly throughout the ventricular muscle tissue, leading to massive ventricular depolarization and subsequent contraction (systole). The ECG measures the summation of these microscopic electrical potential differences as they are conducted through the body tissues to the skin surface. Electrodes attached to the limbs and chest detect these minute voltage changes. The characteristic waves and intervals seen on the ECG represent specific stages of this highly orchestrated conduction sequence. Depolarization moving toward a positive electrode creates an upward deflection, while repolarization, or the recovery phase, generates different characteristic shapes and directions.

### 4. Key Characteristics: ECG Waveforms and Intervals

The standard electrocardiogram tracing is composed of specific waves, segments, and intervals, each corresponding to a particular event in the cardiac cycle. Accurate interpretation requires meticulous analysis of these components:

**P Wave:** This small, rounded wave represents **atrial depolarization** (electrical activation). It signifies the electrical impulse originating from the SA node and spreading through both atria. Abnormally shaped, inverted, or absent P waves can indicate ectopic atrial rhythms or atrial fibrillation.

**PR Interval:** This measures the time from the start of atrial depolarization (beginning of the P wave) to the start of ventricular depolarization (beginning of the QRS complex). It reflects the total

conduction time through the atria and the crucial AV node delay. A prolonged PR interval suggests an AV block, while a shortened interval might indicate accessory conduction pathways (e.g., Wolff-Parkinson-White syndrome).

**QRS Complex:** This sharp, high-amplitude complex represents **ventricular depolarization**. The Q wave is the initial negative deflection, the R wave is the first positive deflection, and the S wave is the negative deflection following the R wave. This complex signifies the strong electrical activation required for the major pumping action of the ventricles. Its width is clinically critical; a widened QRS often indicates intraventricular conduction delays, such as bundle branch block or ventricular tachycardia.

**ST Segment:** This segment begins at the end of the S wave (the J point) and ends at the beginning of the T wave. It represents the period when the ventricles are completely depolarized and are in the plateau phase of the action potential. The ST segment is critically important in diagnosing **myocardial ischemia** or injury; persistent elevation (STEMI) or depression of the ST segment is a hallmark sign of acute coronary syndrome (heart attack).

**T Wave:** This wave represents **ventricular repolarization** (electrical recovery). Changes in the T wave, such as inversion, flattening, or peaking, can indicate ischemia, electrolyte abnormalities (e.g., hyperkalemia), or the pharmacological effects of certain cardiac drugs.

**QT Interval:** This measures the total time required for ventricular depolarization and repolarization, extending from the beginning of the QRS complex to the end of the T wave. Since the heart rate influences its duration, the interval is often corrected (QTc). A prolonged QTc interval is a significant risk factor for life-threatening ventricular arrhythmias, particularly *Torsades de Pointes*.

## 5. Clinical Applications and Diagnostic Utility

The clinical utility of the ECG is expansive, serving as the cornerstone for diagnosing numerous cardiac conditions. In acute care, the 12-lead ECG is the primary, rapid tool for assessing patients presenting with symptoms such as chest pain, palpitations, shortness of breath, or syncope. In cases of suspected **Acute Coronary Syndrome**, the ECG can rapidly confirm a diagnosis of Myocardial Infarction, guiding immediate life-saving treatments like angioplasty or thrombolysis.

The ECG is indispensable in the evaluation of **cardiac rhythm disorders**, or arrhythmias. It allows clinicians to precisely determine the origin and mechanism of rhythm disturbances, distinguishing between relatively benign premature beats and dangerous, unstable rhythms like ventricular fibrillation, atrial flutter, or supraventricular tachycardia. Furthermore, it helps classify the severity of conduction blocks, such as first-, second-, and third-degree AV blocks, which necessitate different management strategies, including pacemaker implantation.

Beyond acute diagnostics, the ECG is used routinely to screen patients for underlying heart disease, evaluate the progression of conditions like ventricular hypertrophy, assess for signs of electrolyte imbalances (e.g., potassium or calcium disorders), and monitor the effectiveness and

side effects of cardiac medications. Its ability to provide immediate, non-invasive data makes it critical across all levels of patient care, from pre-operative screening to long-term chronic disease management.

## 6. Procedure and Technical Considerations

A standard clinical ECG utilizes **12 leads**, which are derived from electrodes placed at specific locations on the patient's limbs and chest. These 12 leads provide 12 distinct electrical viewpoints, offering a comprehensive, three-dimensional perspective of the heart's electrical flow. The leads are categorized into two primary groups: the limb leads and the precordial (chest) leads.

The **Limb Leads** (I, II, III, aVR, aVL, aVF) measure the electrical potential differences between two limbs (bipolar leads) or between one limb and the calculated electrical center of the heart (unipolar augmented leads). These leads view the heart predominantly in the frontal plane, providing information about the superior, inferior, and lateral walls. The six **Precordial Leads** (V1 through V6) are placed directly across the chest wall in specific intercostal spaces and view the heart in the horizontal plane, providing detailed views of the anterior, septal, and true lateral walls.

Correct placement of these electrodes is absolutely paramount; misplacement, particularly of the precordial leads, can lead to significant diagnostic errors. Errors can artificially mimic serious ischemic changes (such as ST elevation) in a structurally normal heart, or, conversely, obscure true pathology, delaying critical intervention. Technical requirements also mandate proper skin preparation to ensure low electrical resistance, preventing artifact and ensuring a clean, diagnostic quality tracing.

## 7. Significance and Impact

The Electrocardiogram remains one of the most significant medical diagnostic inventions of the 20th century. Its impact stems from its simplicity, non-invasiveness, and immediate clinical relevance. It provides crucial, objective feedback on cardiac electrical function that cannot be obtained through physical examination alone. The ability to visualize the conduction system in real-time has fundamentally transformed emergency medicine, enabling rapid triage and accurate treatment decisions that have significantly reduced mortality rates associated with acute coronary syndromes and sudden cardiac arrest. The standardization established by Willem Einthoven ensures that an ECG tracing recorded anywhere in the world can be interpreted consistently by trained medical professionals, making it a universal language of cardiac health. Its reliability and low cost ensure its continued role as the first line of investigation in suspected heart disease.

## 8. Debates and Limitations

While invaluable, the ECG has inherent limitations that necessitate cautious interpretation.

Fundamentally, the ECG is purely a measure of electrical activity and provides no direct information regarding the mechanical pumping function or the structural anatomy of the heart. For instance, a patient can suffer from severe congestive heart failure with low ejection fraction yet present with a completely normal resting ECG. This clinical discordance requires the use of supplementary imaging techniques, such as echocardiography, for structural assessment.

A critical limitation occurs in the context of **Pulseless Electrical Activity (PEA)**, a form of cardiac arrest where the ECG shows organized electrical rhythm, but the heart fails to generate sufficient mechanical force to produce a pulse. In this scenario, the electrical signal is present but ineffective, highlighting the necessity of clinical correlation and assessment of the patient's mechanical status. Furthermore, interpretation requires specialized training; subtle abnormalities, particularly those induced by electrolyte disturbances or pharmacological toxicity, can be easily misinterpreted. Modern clinical practice also faces the challenge of over-reliance on automated interpretation software; while useful for initial screening, these computer readings often misclassify complex rhythms or subtle ischemic changes and must always be verified by an experienced clinician to prevent diagnostic errors.

## 9. Further Reading

[Electrocardiography \(ECG/EKG\) - Wikipedia](#)

[Willem Einthoven - Biographical \(Nobel Prize\)](#)

[The History of the Electrocardiogram - American Heart Association Journals](#)